

00137969

Component


MPZ-LN-01-00-P-P-FA-FA-POL

Serial number

15580-20

| Packaging-interfaces | | | | |
|--|--------------------------------------|------------------|--|--|
| Input fiber | Polarization maintaining, Panda type | | | |
| Output fiber | Polarization maintaining, Panda type | | | |
| Jacket type | 900µm outside diameter | | | |
| Input optical connector (orientation) | FC/APC | Key // slow axis | | |
| Output optical connector (orientation) | FC/APC | Key // slow axis | | |
| Input fiber length | 1.5 meter | | | |
| Output fiber length | 1.5 meter | | | |
| Option | Integrated polarizer | | | |
| Input RF port | 50Ω, female K | | | |

Product dimension and pin-out



Thickness : 9.6mm Material : KOVAR Package dimensions in mm

Measured with : Emcore laser module λ = 1550 nm

| Conditions | | Measurements | Specifications |
|-----------------------|---|--|---|
| with input connection | dB | 3,5 | ≤3.75 |
| @50kHz | V | 3,2 | ≤3.5 |
| between 0 – 1.5GHz | dB | -16,3 | ≤-12 |
| @ -3dB, from 500MHz | GHz | >1 | >1 |
| | with input connection @50kHz between 0 – 1.5GHz | with input connectiondB@50kHzVbetween 0 – 1.5GHzdB | with input connection dB 3,5 @50kHz V 3,2 between 0 – 1.5GHz dB -16,3 |

| Position | Name/Visa | Date |
|---------------|-----------|------------|
| Test engineer | R.ROWLAND | 2024-06-25 |

Precautions of use :

For bias control and modulation signal, please refer to the Application Note "LiNbO3 Intensity Modulators Bias Control and Modulation Driving". This application note aims to give intensity modulators users the basics to select and apply the proper RF and bias voltages to their device and can be downloaded from our company website www.photonics.ixblue.com

In order to avoid any damage to the modulator and to keep its performance at maximum, please pay a special attention to the following :

When handling the modulator, do not apply any excessive tensile strength neither bend on the fiber pigtails.

•• Always keep the optical connectors end face protected and clean the optical connector end face with appropriate tissue before

••• Clean RF connector with dry air before mating and use a torque wrench for tightening.

•••• Respect maximum ratings mentioned in accordance with specifications (www.exail.com/event_category/photonics.com)

••••• At the maximum optical power, fusion splices are expressly recommended to avoid permanent damage on optical connectors.

•••••• In the case of optical instabilities, when operating at high optical power or shorter wavelength, it might be necessary to heat up the modulator (max 50°C)



EXAIL, Photonic Solutions Division 3, rue Sophie Germain 25000 Besançon, France Tél : +33 1 30 08 88 88 Fax : +33 1 30 08 88 00